



70161

Baby Sprinkles SPLISH SPLASH POOL™





IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ AND SAVE THESE INSTRUCTIONS BEFORE SETUP AND USE.
KEEP THESE INSTRUCTIONS IN A SAFE PLACE FOR FUTURE REFERENCE.


FOR AGES 18 MONTHS+
ADULT SET UP IS REQUIRED.

Part List

1. Inflatable activity pool x 1



2. Inflatable whale slide x 1



3. Inflatable rainbow canopy x 1



4. Inflatable dolphin rider x 1



5. Inflatable starfish stacking ring x 4



6. Repair patch x 1



DO NOT RETURN TO STORE

THIS PRODUCT CANNOT BE RETURNED FOR A REFUND AFTER IT HAS BEEN UNPACKED AND USED.

FOR QUESTIONS OR PROBLEMS WITH THIS PRODUCT PLEASE EMAIL BELOW ADDRESS FOR EXPEDITED ASSISTANCE

CUSTOMERSERVICE@TOYSINQUIRY.COM



Safety Information

Warning!

To avoid the risk of serious injury or death;

- Place on level ground.
- Setup should be done from a safe distance away from fences, garages, houses, overhanging branches, laundry lines or overhanging electrical wires.
- Do not setup or use on concrete, asphalt or any other hard surfaces.
- Read all instructions before using this product.
- Disregard of and not following the instructions from manual and warnings could result in injury or death, especially for children.
- Fill with clean, cold tap water only. (other liquids may be harmful to people and the water blaster).
- Do not insert anything inside nozzle.
- Do not attempt to alter the nozzle. (This may damage the product and will not function properly.)
- Do not allow sand or dirt to get inside the nozzle.
- Do not allow anyone to use this product who is under the age of 18 months.

While every attempt is made to embody the highest degree of protection in all equipment, we cannot guarantee freedom from injury. The user assumes all risk of injury resulting from use. All merchandise is sold on this condition, which no representative of the company can waive or change.

IMPORTANT WATER PRESSURE AND OPERATING INFORMATION

After connecting the hose connector to garden hose, TURN ON WATER SLOWLY and adjust the water pressure accordingly.

Water pressure can vary dramatically between cities. Please read the following for answers to common questions.

Areas of LOW WATER PRESSURE

- For maximum performance, it is recommended to use a 5/8 in (1.6cm) diameter garden hose.
- If water does not arch on the product / spray properly, it is usually due to low water pressure. Make sure the water is on all the way. As long as the product is getting wet, it will be fun to use.
- Long hose reduces water pressure: The longer the hose, the farther the water travels from the faucet thus reducing water pressure. In areas of low water pressure, this could affect the performance of the product. Try using a shorter hose if you have one.

Areas of HIGH WATER PRESSURE

- If water arches / sprays over the product adjust the faucet to lower the water pressure. It is important that the water lands on the product to keep it wet and slick.

Maintenance

- Check the pool and slide at regular intervals for holes, tears or other damage. DO NOT use a damaged pool and slide. Use of a damaged pool and slide could result in serious injury or death.
- In addition to checking the product at regular intervals, be sure to complete a thorough check of the entire product at the beginning of each season or series of use.
- If any components of the product are damaged or have deteriorated, discontinue use and contact the manufacturer.
- Regularly check the condition of water plug and water bag that hold the slide in place. Damage to or deterioration of the water bag could result in the slide becoming unstable, which could result in serious injury.

Repair Patch Instructions

For your convenience, a repair patch has been included to repair holes in the inflatable section.

Do not use the patch for holes or rips on the seam.


In the event of an accidental puncture, cut out a suitably sized patch. Make sure you round the corners of your repair patch to avoid peeling. Make sure area to be patched is clean and dry. Press patch firmly over the puncture. Do not inflate for 20 minutes.

Setup Instructions

1. Placement diagram:

Use on flat lawn only, not on pavement or other hard surfaces. Lawn should be free of rocks, bumps, depressions, sticks, etc. This product should be setup in a location that has a minimum distance of 10 ft (305 cm) away from any freestanding structures or obstructions including: houses, garages, fences, trees, playground equipment and large rocks.

1.



2. Roll out this product. Inspect for holes, tears or other damage.

2.




3. Use hose to fill water bag on the bottom of the whale slide.

NOTE: You must fill the water bag before inflating this product with air.

WARNING: Overfilling water bag will cause damage to inflatable whale slide.

NOTE: When filling the water bag do not completely insert a hose into the water valve. The hose may cause the pressure in the water bag to increase and the water bag may burst. Use a garden hose to gently pour water into the water bag. When full, close the valve.

3.



Setup Instructions

4. Inflate this product with AIR.

NOTE: For easy air inflation use a manual air pump designed specifically for plastic inflatables.

5. **BY MOUTH:** Remove the air valve plug and squeeze the base of the valve causing the inner flap to open for inflation.


BY PUMP: Remove the air valve plug and insert air pump nozzle into the valve. The air pump nozzle should be inserted deep enough to open the inner valve flap.

Do not over inflate the item. Once the item is completely inflated, then insert the air valve plug to seal it shut.


NOTE: Fill inflatable with air until it is firm and solid. If there is any straining at the seams, the item is over inflated. If any seam begins to strain, immediately stop inflation and release air to reduce the pressure until all signs of stress on the inflatable are gone. **DO NOT** use the inflatable if there is straining at the seams. Use of an over-inflated item may result in serious injury, paralysis or death.

Inspect this product for rips, tears or punctures. Do not use if damaged.

4.



5.



Setup Instructions


6. Place the whale slide over the pool rim. Ensure that the end of the slide is at the soft clam shell landing pad.

7. Attach the end of a standard garden hose to the hose connector. Turn the connector to tighten; tighten until it cannot turn any further.

6.



7.



Use Instructions



How to play

Explore the ocean with your sea creature friends in the Baby Sprinkles Splish Splash Pool™! Slide down the whale's back and land on the water spraying clamshell. Hang out under the palm tree and get squirted by the starfish stacker. You can even ride a baby dolphin or grab some shade under the colorful rainbow. Playtime has never been this much fun!

Note:

1. Competent adult setup and supervision is required at all times. Responsible adults should instruct children on the proper use of this product.
2. Remove all hard or sharp objects such as toys, buckles, keys, jewelry, watches, etc., from person and pockets.
3. NEVER DIVE HEAD FIRST.
4. No diving.

PLEASE RETAIN THIS
INFORMATION
FOR FUTURE REFERENCE.
COLORS AND CONTENTS
MAY VARY.

TOYQUEST®

HUZHEN TOWN, BOLUO,
HUIZHOU, CHINA
ALL RIGHTS RESERVED
MADE IN CHINA
www.toysinquiry.com

After Use and Storage

1. Disconnect garden hose from the hose connector. Make sure this product is completely free of grass, leaves, sand, twigs, dirt, etc. This will lengthen the life of this product.

2. Drain the product and let it dry.

3. **PUTTING YOUR PRODUCT AWAY:**
Make sure the product and its accessories are free of dirt, leaves, sand, etc., before deflating.

4. When this product is completely dry, carefully roll it up and store in a secure location away from children. Do not store it indoors or in a closed container until it is completely dry.

Note:

1. Store this product in a secure place, away from children, to prevent suffocation.
2. If the water of the pool is changed regularly (around every 8 hours) we do not recommend any special treatment for the water.

